

Bristle Filter Instructions For STF-110 4" (Installation & Maintenance)

<u>Instructions for installation in standard 4" outlet "Tee" of septic tank.</u>

- Orient the filter so that the wire handle faces opposite the discharge outlet.
- Push filter into top of "Tee" until the 90 degree wire handle touches the top of the "Tee". The filter is now "installed", as shown in the picture to the right.
- The flexibility of the STF-110 bristle filter allows it to be used in just about any situation. If you need help with a custom installation please call Sim/Tech Filter toll free at 888-999-3290.



Recommended maintenance schedule

For maximum protection, it is recommended that the filter be replaced annually. If not, it should be inspected at least once per year. The filter is capable of lasting three years under normal conditions. Such factors as garbage disposals, pets, laundry, etc. may cause the need for more frequent inspection or service.

<u>Instructions for performing maintenance in standard 4" outlet "Tee" of septic tank.</u>

• Before removing filter, one of two options must be performed. These options need to be performed to prevent any outflow of unfiltered effluent from the tank while the filter is removed.

Option 1

Insert a STF-130 maintenance sleeve (sold separately) with the handle coupling on the same side of the "Tee" as the outlet hole. Push the sleeve into the "Tee" until the handle coupling hits the top of the "Tee". Do not remove the sleeve until a filter has been put back in the "Tee".

Option 2

Have the tank pumped down by a professional septic service company.

- After performing one of the options above, remove filter by pulling up on the filter handle.
- Place the used filter in the provided plastic bag for proper disposal.
- Install a new replacement filter as described in the installation instructions at the top of the page.
- If a maintenance sleeve was used (option 1), remove the sleeve from the outlet "Tee".



Maintenance Sleeve partially inserted into "Tee"

U.S. Patent # 6,811,692



STF-130 Maintenance • Sleeve